

W3D- IC BOX WITHOUT TANK

System power on & auto delay 8s

Making pure water

CLOSE WATER

Set flush time then flush for 35s before standby

- 1. Operation "delay" function:
 - a.To prevent unstable water pressure to cause of intermittence operation
 - b. Filter Container drawdown for user friendly on water leakage design while exchanging filter
- 2.Flush setting:Flush duration it depends water quality & usage
- 3. The flush function not executable while making pure water, need to switch off output pipe.
- 4.Flush setting:

Scale/3mins, 1=3min; A ~ F = 10min ~ 15min; 0=Function Disable

5.Flush button:

Filter exchange, Filer container exhaust, avoid void block; overloading function disable (RESET).